7295B/L

Image Orthicon

LONG-LIFE TARGET MAGNETIC FOCUS

FIELD-MESH TYPE
MAGNETIC DEFLECTION

For High-Quality Black-and-White TV Pickup in Studio or Outdoor Service. The 7295B/L is Directly Interchangeable with the 7295, 7295A, and 7295B in all Cameras.

The 7295B/L is the same as the 7295B except utilizes a stable, long-life glass target.

The stable, long-life, glass target of type 7295B/L is characterized by high gain, resistance to "burn-in", and the absence of any granular structure. Because charge transportation through this target material is electronic rather than ionic as in ordinary glass targets, the electrical characteristics of the target, such as secondary emission and resistivity, are essentially constant and sensitivity of the 7295B/L is stable throughout life.

Other important advantages of this target are that the undesirable characteristics of scene retention or "sticking picture" and raster "burn-in" due to underscanning are significantly reduced. The resistance of the 7295B/L to image "burn-in" provides a highly desirable operational feature because it is not necessary to use an orbiter or continually move the camera when focused on a stationary scene.

OPERATING CONSIDERATIONS

Dos and Don'ts on Use of RCA-7295B/L Dos

- 1. Allow the 7295B/L to warm up prior to operation.
- 2. Hold temperature of the 7295B/L within operating range.
- 3. Make sure alignment coil is properly adjusted.
- 4. Adjust beam-focus control for best usable resolution.
- 5. Condition spare 7295B/L's by operating several hours once each month.
 6. Determine proper operating point with a record of the condition of the con
- Determine proper operating point with target voltage adjusted to the desired voltage above target cutoff.
- 7. Uncap lens before voltages are applied to the 7295B/L.

Don'ts

- 1. Don't force the 7295B/L into its shoulder socket.
- 2. Don't operate the 7295B/L without scanning.
- 3. Don't operate a 7295B/L having an ion spot.
- Don't use more beam current than necessary to discharge the highlights of the scene.
- Don't turn off beam while voltages are applied to photocathode, grid No.6, target, dynodes, and anode during warmup or standby operation.